

FOTELIK PIANKOWY

Dane producenta:

KMH Marlena Klupś

Ul. Warszawska 9,

63-820 Piaski

E-mail: sprzedaz@alberomio.pl

tel.+48 607 814 477

Bezpieczeństwo użytkowania:

- Przeznaczony dla dzieci od około 12 miesiąca do około 5 lat, w zależności od wagi i wzrostu dziecka – zawsze kieruj się indywidualnym rozwojem dziecka.
- Produkt nie jest zabawką – fotelik służy wyłącznie do siedzenia i wypoczynku.
- Używać wyłącznie pod nadzorem osoby dorosłej.
- Sprawdzaj stan fotelika przed każdym użyciem. W przypadku jakichkolwiek uszkodzeń, rozdarć lub śladów zużycia, natychmiast zaprzestań używania.
- Trzymaj produkt z dala od ognia, źródeł ciepła oraz ostrych przedmiotów.
- Upewnij się, że dziecko korzysta z fotelika w sposób zgodny z jego przeznaczeniem – nie pozwalaj na wspinanie się, skakanie ani wykorzystywanie go jako elementu zabawy.
- Umieść fotelik na stabilnej, płaskiej i suchej powierzchni.
- Upewnij się, że wokół fotelika jest wystarczająco dużo miejsca, aby dziecko mogło swobodnie usiąść i wstać.
- Przechowuj fotelik w suchym, czystym miejscu, z dala od bezpośredniego nasłonecznienia, grzejników i innych źródeł ciepła, które mogłyby uszkodzić piankę lub zmienić jej właściwości.
- Opakowanie produktu nie jest zabawką – należy je przechowywać poza zasięgiem dzieci, ze względu na ryzyko uduszenia.
- Zalecamy recykling opakowania zgodnie z lokalnymi zasadami ochrony środowiska.

Pielęgnacja i przechowywanie:

- Czyść fotelik zgodnie z zaleceniami producenta dostępnymi na metce produktu - prać tylko zdejmowany pokrowiec.
- Przechowuj w suchym, czystym miejscu, z dala od bezpośredniego działania promieni słonecznych.

Odpowiedzialność za prawidłowe użytkowanie:

- Rodzic/opiekun powinien zawsze nadzorować dziecko podczas używania przez dziecko fotelika, aby upewnić się, że fotelik jest prawidłowo użytkowany tylko w sposób do tego przeznaczony.
- Regularnie sprawdzaj stan fotelika, szczególnie w okolicach szwów i zamka, aby upewnić się, że materiał nie uległ uszkodzeniu, a zamek jest prawidłowo zasunięty.

Sposób użycia:

- Wybierz odpowiednie i bezpieczne miejsce. Umieść fotelik na stabilnej, płaskiej powierzchni, z dala od krawędzi i potencjalnych zagrożeń.
- Delikatnie posadź dziecko w foteliku lub pozwól dziecku usiąść samodzielnie. Upewnij się, że siedzi ono stabilnie w foteliku.
- Nigdy nie zostawiaj dziecka samego w foteliku, zwłaszcza jeśli jest ono zbyt małe, aby samodzielnie utrzymać równowagę.
- Regularnie sprawdzaj, czy fotelik jest czysty i nie ma na nim żadnych uszkodzeń.

Informacje dodatkowe:

- Produkt uszyty w Polsce z wysokiej jakości materiałów posiadających certyfikat Oeko – tex gwarantujący bezpieczeństwo dla najmłodszych.
- Producent informuje, że pokazana na zdjęciu kolorystyka może nieznacznie różnić się od rzeczywistego produktu.
- Odcienie druku na tkaninach bądź odcienie surowców składowych produktów mogą różnić się w zależności od partii produkcyjnych. Nie stanowi to wady produkcyjnej.
- Naturalne zużycie produktu, w tym blaknięcie barw spowodowane częstym praniem czy ekspozycją na promienie słoneczne, a także uszkodzenia mechaniczne powstałe w wyniku nieprawidłowego użycia lub nadmiernego naprężenia (np. rozdarcia, wyrwane zamki, gumki, guziki czy troczki), nie stanowią podstawy do reklamacji.

BABY ARMCHAIR

Producer data:

KMH Marlena Klupś

Ul. Warszawska 9,

63-820 Piaski

E-mail: sprzedaz@alberomio.pl

mob.+48 607 814 477

Safety of use:

- Designed for children from approximately 12 months to approximately 5 years, depending on the child's weight and height - always follow the child's individual development.
- The product is not a toy - the baby armchair is for sitting and resting only.
- Use only under adult supervision.
- Check the condition of the seat before each use. In the event of any damage, tears or signs of wear, discontinue use immediately.
- Keep the product away from fire, heat sources and sharp objects.
- Make sure that the child uses the baby armchair in a manner consistent with its intended use - do not allow climbing, jumping or using it as an element of play.
- Place the baby armchair on a stable, flat and dry surface.
- Make sure that there is enough space around the baby armchair for the child to sit and stand up freely.
- Store the baby armchair in a dry, clean place, away from direct sunlight, radiators and other sources of heat that could damage the foam or change its properties.
- The product packaging is not a toy - it should be kept out of the reach of children due to the risk of suffocation.
- We recommend recycling the packaging according to local environmental regulations.

Care and storage:

- Clean the baby armchair according to the manufacturer's instructions on the product label - only wash the removable cover.
- Store in a dry, clean place, away from direct sunlight.

Responsibility for correct use:

- A parent/guardian should always supervise the child when the child is using the baby armchair to ensure that the seat is used correctly and in the manner intended.
- Regularly check the condition of the baby armchair, especially around the seams and zipper, to ensure that the material is not damaged and that the zipper is closed correctly

How to use:

- Choose a suitable and safe place. Place the seat on a stable, flat surface, away from edges and potential hazards.
- Gently place your child in the baby armchair or let them sit up on their own.
- Make sure they are sitting steadily in the armchair.
- Never leave your child alone in the seat, especially if they are too small to balance on their own.
- Regularly check that the seat is clean and free from any damage.

Additional information:

- Product sewn in Poland from high-quality materials with the Oeko-tex certificate, guaranteeing safety for the youngest.
- The manufacturer informs that the colors shown in the photo may differ slightly from the actual product.
- The shades of the print on fabrics or the shades of the raw materials used in the products may vary depending on the production batches. This does not constitute a manufacturing defect.
- Natural wear and tear of the product, including fading colors caused by frequent washing or exposure to sunlight, as well as mechanical damage resulting from improper use or excessive stress (e.g. tears, torn zippers, elastic bands, buttons or strings), do not constitute grounds for complain.

